




WR97XX Windrowers

Turning on autosteer engage switch on joystick





Important Note: Header must be engaged for joystick auto steer engage to work

